
Screw-on levels

for mounting with screws







Sensitivity

- 6 Angle minutes, bubble move by 2 mm
- 50 Angle minutes, bubble move by 2 mm


5 Identification no.

- 1 Viewing window top
- 2 Viewing window top front
- 3 Viewing window top front back

•	
74	
v	

I ₁	b	d	h ₁	h ₂	l ₂	m
57	12	4,5	13	1	37	45

Specification





G

- Spirit level element Glass plastic body Filling
- Casting compound mineral-based
- RoHS compliant

On request

- Filling, colourless-transparent
- Other sensitivities
- Other colours

Information

Screw-on levels GN 2282 are used to check the horizontal position of jigs, machines, devices, appliances and instruments.

The spirit levels are aligned in relation to the finished reference surface so that the bubble is centered in the middle of the marking lines once the horizontal position of the contact surface in the longitudinal direction is reached.

see also...

• General information on bull's eye levels and screw-on levels → Page 75

