




MATERIAL

Brass.

FEATURES AND APPLICATIONS

GH. nuts can be used for fitting the following indicators to reservoirs with thin walls (thickness smaller than 5 mm):

- HGFT. (see page 1188)
- HGFT-EX (see page 1189)
- GN 743 (see page 1190)
- GN 743.1 (see page 1190)
- GN 743.2 (see page 1191)
- GN 743.3 (see page 1192)
- GN 743.4 (see page 1193)
- GN 743.5 (see page 1193)
- GN 743.6 (see page 1196)
- HGFT-PR (see page 1198)
- HGFT-HT-PR (see page 1198)
- GN 744 (see page 1199)
- HFTX. (see page 1202)
- HFTX-PR (see page 1203)
- HCFE. (see page 1204)
- HCFE-C (see page 1204)
- HCFE-EX (see page 1205)



Code	Description	d1	B	s	⚖️
14991	GH. 1/4	G 1/4	6	19	9
15001	GH. 3/8	G 3/8	3	19	3
15011	GH. 1/2	G 1/2	4	26	8
15021	GH. 3/4	G 3/4	5	31	12
15031	GH. 1	G 1	4.5	37	14
15041	GH. 1 1/4	G1 1/4	5	46	23
15051	GH. 2	G 2	6	65	50