



- 4 Sensitivity**
- 30** Angle minutes, bubble move by 2 mm
- 5 Type**
- A** Mounting flange for bolting to surface
- B** Mounting flange for inserting (collar)

2

d ₁	d ₂	d ₃	d ₄	d ₅	h ₁	h ₂
20	10	14	17	1,8	10	1,8
25	12	17	21	2,2	10	2
30	12	18	24	3,2	11	3
40	20	28	34,5	3,2	14	4
50	25	34	43	3,2	15	5

Specification

- Housing
Aluminium
anodized, natural colour **ALN**
anodized, black **ALS**
- Spirit level element
Glass plastic body
Filling
colourless-transparent **K**
- Casting compound
mineral-based
- **RoHS compliant**

On request

- Filling, green-transparent
- Other sensitivities
- Housing in brass or Stainless Steel

1 3

Information

Bull's eye levels GN 2277 are used to check the horizontal position of jigs, machines, devices, appliances and instruments.
The spirit levels are aligned in relation to the reference surface so that the bubble is located inside the marking ring when the horizontal position of the contact surface is achieved.

see also...

- *General information on bull's eye levels and screw-on levels* → Page 75
- *Adjustment plates GN 2277.1* → Page 78

How to order

1	Material / Finish
2	d₁
3	Filling
4	Sensitivity
5	Type

GN2277-ALS-50-K-30-A