

<sup>1</sup> $d_1 -0,5$	<sup>2</sup> $l_1 +2$	$a_1$	$a_2$	$d_2$	$h_1$	$h_2 -0,1$	$l_2$
30	100	18	9	32	34,5	14,5	106
30	200	18	9	32	34,5	14,5	206
30	300	18	9	32	34,5	14,5	306
30	400	18	9	32	34,5	14,5	406
30	500	18	9	32	34,5	14,5	506

**Specification**

<sup>3</sup>

- Tube extrusion  
Aluminum
- End caps  
Zinc die casting
- Tube extrusion / End caps  
plastic coated  
black, RAL 9005, textured finish ● **SW**
- Self tapping countersunk screws  
DIN 7500-1, type M with Torx®
- **RoHS compliant**

**Information**

The tube extrusion for edge handles GN 481 is formed in such a way that two countersunk self tapping screws are used to cut their own counter thread in the extrusion to hold the end caps in position.

If an edge handle for a cabinet of non-standard length is required, a standard extrusion can simply be shortened to fit.

**Accessory**

- Four DIN 7500-1 countersunk screws are included.


**On request**

- Tube extrusion,  
anodized, natural color
- End caps, plastic coated  
silver, textured finish

**How to order**

**GN 481-30-300-SW**

<sup>1</sup>	$d_1$
<sup>2</sup>	$l_1$
<sup>3</sup>	<b>Finish</b>



1.1

1.2

1.3

1.4

### Mounting information

In order to align the edge handle with the edge of the cabinet (tolerance  $l_1 + 2 \text{ mm}$ ), the end caps should, to start with, only be loosely fitted.

The mounting is carried out in two steps as follows:

1. Fit the end caps firmly to the cabinet.
2. Fix the extrusion axially by using the countersunk screws.

2.1

2.2

2.3

2.4

