


**2 Identification No.**

2 with 2 Stainless Steel-Clamping screws DIN 912



1 1

d <sub>1</sub> Bore B	s Square V	d <sub>2</sub>	d <sub>3</sub> Clamping thread	k Clamping length	l <sub>1</sub>	l <sub>2</sub>	l <sub>3</sub>	t	x <sub>1</sub>	x <sub>2</sub>	y <sub>1</sub>	y <sub>2</sub>	y <sub>3</sub>	Clamping kit for d <sub>3</sub>
B 20	V 20	7	M 8	58	69	46	146	7	75	60	72	35	30	GN 911-M 8-40
B 25	V 25	7	M 8	58	69	46	146	7	75	60	72	35	30	GN 911-M 8-40
B 30	V 30	7	M 8	58	69	46	146	7	75	60	72	35	30	GN 911-M 8-40
B 40	V 40	11	M 10	91	98	70	218	14	115	90	108	50	45	GN 911-M10-63
B 42	-	11	M 10	91	98	70	218	14	115	90	108	50	45	GN 911-M10-63
B 45	V 45	11	M 10	91	98	70	218	14	115	90	108	50	45	GN 911-M10-63
B 48	-	11	M 10	91	98	70	218	14	115	90	108	50	45	GN 911-M10-63
B 50	V 50	11	M 10	91	98	70	218	14	115	90	108	50	45	GN 911-M10-63

**Specification**

- Aluminum
  - plastic coated black, RAL 9005, textured finish ● **SW**
  - blank ○ **BL**
  - matt shot-blasted
- Clamping bores not machined
- Socket cap screws DIN 912  
Stainless Steel AISI 304
- Hexagon nuts DIN 985  
Stainless Steel AISI 304
- Stainless Steel characteristics → Page 1144
- RoHS compliant

**Accessory**

- Clamping kits GN 911 → Page 1031

**Information**

The clamping bores of GN 167 wide base plate connector clamps are not machined and specially designed for construction tubes GN 990 or DIN 2391, DIN 2395 and DIN 2462 respectively.

The square designs are also suitable for use in **profile systems**.

The standard version of the clamping screws are socket cap screws with hexagonal socket DIN 912. They can be replaced by clamping kits GN 911 (article code see table of dimensions).

see also...

- Construction tubes GN 990 → Page 1027

How to order

GN 167-V30-2-SW

- 1 s (d<sub>1</sub>)
- 2 Identification No.
- 3 Finish