



d <sub>1</sub> Ø	d <sub>2</sub> Ø	w <sub>1</sub>	l <sub>1</sub>	l <sub>2</sub>	for tube GN 990
D 10	6 ... 8	1 ... 2	10	4	D 10
D 12	9 ... 10	1 ... 1,5	14	4	D 12
D 14	10 ... 12	1 ... 2	14	4	D 14
D 15	10 ... 13	1 ... 2,5	15	3	D 15
D 16	12 ... 14	1 ... 2,5	15	5	D 16
D 18	13 ... 16	1 ... 2,5	16	5	D 18
D 20	15 ... 18	1 ... 2,5	17	5	D 20
D 25	20 ... 23	1 ... 2,5	17	5	D 25
D 30	25 ... 28	1 ... 2,5	17	5	D 30
D 32	27 ... 30	1 ... 2,5	17	5	D 32
D 35	30 ... 33	1 ... 2,5	17	5	D 35
D 40	30 ... 34	3 ... 5	17	5	D 40
D 42	35 ... 37	2,5 ... 3,5	17	5	D 42
D 45	38 ... 43	1 ... 3,5	17	5	D 45
D 48	40 ... 42	3 ... 4	20	5	D 48
D 50	43 ... 45	2,5 ... 3,5	23	5	D 50
D 55	45 ... 49	3 ... 5	20	5	D 55
D 60	54 ... 56	2 ... 3	22	4	D 60



s <sub>1</sub> □	s <sub>2</sub> □	w <sub>2</sub>	l <sub>3</sub>	l <sub>4</sub>	for tube GN 990
V 10	6 ... 8	1 ... 2,5	14	4	V 10
V 12	8 ... 11	0,5 ... 2	16	4	V 12
V 16	12 ... 14	1,5 ... 2	17	5	V 16
V 20	15 ... 18	1 ... 2,5	17	5	V 20
V 25	20 ... 23	1 ... 2,5	17	5	V 25
V 30	25 ... 28	1 ... 2,5	17	5	V 30
V 35	30 ... 33	1 ... 2,5	20	5	V 35
V 40	34	3	20	5	V 40
V 45	39 ... 43	1 ... 3	20	5	V 45
V 50	40 ... 45	2,5 ... 5	24	5	V 50

**Specification**

- Plastic (Polyethylen PE)  
black
- *Plastic characteristics* → Page 1141
- **RoHS compliant**

**Information**

Tube end plugs GN 991 have been designed for sealing tube ends for safety or optical reasons.

They are pressed into the tube end either by hand or with a mallet.

see also...

- *Construction tubes GN 990* → Page 1027
- *Insert bushes GN 348 (Plastic, with female thread)* → Page 842
- *Insert bushes GN 992 (Aluminium, with female thread)* → Page 1029

How to order

**GN991-V25**

1 s<sub>1</sub> (d<sub>1</sub>)