



### 3 Identification No.

2 with 6 Stainless Steel-clamping screws DIN 912

1

1

2

d <sub>1</sub> Bore B	s Square V	k Clamping length	d <sub>2</sub> Clamping thread	l <sub>1</sub>	l <sub>2</sub>	l <sub>3</sub>	m	Clamping kits for d <sub>3</sub>
B 20	V 20	50	M 8	172	68	46	86	GN 911-M 8-40
B 25	V 25	50	M 8	172	68	46	86	GN 911-M 8-40
B 30	V 30	50	M 8	172	68	46	86	GN 911-M 8-40
B 30	V 30	60	M 8	203	79	59	101,5	GN 911-M 8-55
B 32	-	60	M 8	203	79	59	101,5	GN 911-M 8-55
B 35	V 35	60	M 8	203	79	59	101,5	GN 911-M 8-55
B 40	V 40	60	M 8	203	79	59	101,5	GN 911-M 8-55
B 40	V 40	76	M 10	254	98	70	127	GN 911-M10-63
B 42	-	76	M 10	254	98	70	127	GN 911-M10-63
B 45	V 45	76	M 10	254	98	70	127	GN 911-M10-63
B 48	-	76	M 10	254	98	70	127	GN 911-M10-63
B 50	V 50	76	M 10	254	98	70	127	GN 911-M10-63

## Specification

- Aluminium
  - plastic coated  
black, RAL 9005, textured finish ● **SW**
  - blank ○ **BL**  
matt shot-blasted
- Clamping bores not machined
- Socket cap screws DIN 912  
Stainless Steel AISI 304
- Hexagon nuts DIN 985  
Stainless Steel AISI 304
- Stainless Steel characteristics → Page 1144
- RoHS compliant

## Accessory

- Clamping kits GN 911 → Page 1031

4

## Information

The clamping bores of the T-Angle connector clamps GN 195 are not machined and specially designed for construction tubes GN 990 or DIN 2391, DIN 2395 and DIN 2462 respectively.

The square designs are also suitable for use in **profile systems**.

The standard clamping screws are socket cap screws DIN 912. They can be replaced by clamping kits GN 911 (article code see table of dimensions).

see also...

- Construction tubes GN 990 → Page 1027

### How to order

1 2 3 4  
**GN 195-V35-60-2-SW**

1 s (d<sub>1</sub>)  
2 k  
3 Identification No.  
4 Finish